

Business Name: Mid-State Sewer Service

Address: 8754 Cottonwood Dr, Freeland, MI 48623

Phone: (989) 482-7976

Mid-State Sewer Service

We at Mid-State Sewer Service offer a range of cleaning services including video camera inspection, main line sewer cleaning, kitchen and bathroom sink cleaning, shower and bathtub drain cleaning, toilet backups, floor drain cleaning, crawl space clean out entry, roof vent cleaning, drain tile cleaning, storm drain cleaning, hydro jetting, and sewer/ septic backups. We also provide portable toilet rental services.

[View on Google Maps](#)

8754 Cottonwood Dr, Freeland, MI 48623

Business Hours

- Monday through Sunday: Open 24 hours

Follow Us:

- Facebook: <https://www.facebook.com/MidStateSewer>
- YouTube: <https://www.youtube.com/@Midstatesewerservice>

Explore this content with AI:

 [ChatGPT](#)  [Perplexity](#)  [Claude](#)  [Google AI Mode](#)  [Grok](#)

A property owner typically fulfills excavation the same method a driver fulfills a pothole in the evening, far too late to swerve and with a sickening thump. One day the yard is fine, the next there is effluent appearing by the maple tree and your plumber is stating words like collapse, replacement, and allowing. Excavation fits. A crushed structure sewer will not repair itself, and a leach field that has reached completion of its life requires proper septic installation. But in many homes and small companies, the roadway to the backhoe is paved with little, avoidable misses out on, especially around ignored drain cleaning and extended septic pumping intervals.

I have enjoyed modest options conserve clients five figures and entire summer seasons of lawn. I have actually likewise seen well-meaning individuals put hundreds into miracle additives while overlooking the oily spoon of a cooking area line that was the real problem all along. Excellent outcomes rarely depend upon a single product. They originate from a calm, repeatable framework: read the symptoms, collect the ideal information, act in the least expensive lane initially, then intensify just as the truths demand.



How household pipes and onsite systems really fail


From sink to soil, your wastewater passes through brief stretches where specific issues prevail. Understanding those choke points is half the battle.

Inside your house, the cooking area branch is the nuisance. Fats, oils, and grease bond to pipe walls and capture lint, coffee grounds, and those errant noodles that slip past the strainer. Bathrooms produce their own issues with wipes that declare to be flushable however act like tiny tarps. Hair and soap residue assist them weave mats in the lines. Basements often have long, shallow runs where any little stomach collects whatever heavier than water. The structure sewer that leaves the structure is where you meet roots, specifically in older clay or Orangeburg lines, and seasonal ground motion can pull joints apart. One droop of 3 to 6 feet can produce a long-term slow spot.

At the sewage-disposal tank, 2 mistakes do most of the damage. Initially, extending the time between septic pumping permits the scum and sludge layers to rise, pressing solids to the outlet. When the filter obstructions or, even worse, solids reach the circulation box, you start to foul the leach field. Second, letting a high inflow event, such as a leaking toilet or an all-day irrigation mishap that discards into a sump line, overwhelm the tank turns a settlement device into a conveyor. Solids do not have time to settle.

In the field, failure shows up as either hydraulics or biology. Hydraulics is uncomplicated. If your soil has a perched water level for months, the trenches never rest. A remodel that doubled fixtures without upsizing the system can create the exact same overload. Biological failure originates from a thick biomat that no longer passes effluent at a typical rate. A healthy biomat is expected, it polishes wastewater. A starved field, covered with years of grease and cleaning agent providers, can choke and send out water to daylight. Frost depth, traffic load, and landscaping can all exacerbate the mix.

The early signs whisper. Drains gurgle just on laundry day. A faint sewage smell appears after a big vacation. The spot of yard above your line greens up before the rest of the lawn in spring. Individuals tend to explain these away. You ought to not. Those are the minutes when a little, planned service call avoids the excavation later.



Preventative drain cleaning is your first line of defense

Drain cleaning utilized to suggest a cable device and a hope that the obstruction was soft. We still cable particular lines, however the series of tools has actually grown and the thinking has actually matured. The objective is not just to bring back circulation today. The objective is to keep the interior of the pipeline as near self-cleaning speed as you can, with the least abrasive method that does the job.

A camera inspection addresses 2 questions you can not guess accurately: what is the pipeline made from and what is the condition inside. PVC responds in a different way than cast iron or clay. With cast iron, we often see scale that turns a 4 inch line into a 2 inch choke. With clay, we see roots at every joint. Understanding this lets us select [Mid-State Sewer Service Drain Cleaning](#) the right technique. A straight cable can punch a hole through a clog, but it rarely scrubs the walls. A chain flail can descale cast iron effectively when coupled with a camera so we do not thin the pipeline to failure. Hydro jetting, which uses pressurized water at regulated gallons per minute, is gentle on plastic, searches grease in kitchen branches, and can cut roots when paired with a turning nozzle. It also flushes debris downstream, which is why you open and use cleanouts instead of pressing junk toward the tank.

People ask about enzymes and germs. The ideal septic bacteria inside the tank can help digest residue, however they do not replace mechanical cleaning in a grease-choked cooking area line. The drain line is not a comfortable fermenter. Temperature levels swing and detergents break cell walls. I have actually determined lines after heavy enzyme usage and saw absolutely nothing budge. Usage biology where biology lives, inside the tank and field. Leave grease to physics.

Frequency depends upon usage. A household that cooks daily and runs a garbage disposal will build grease faster than a couple who consumes light and garden composts. Beauty parlor, day care centers, and short term rentals push lines difficult in bursts, which welcome slugs of debris. For lots of homes, examining and jetting the kitchen branch each to 3 years keeps surprise clogs at bay. The main to the tank often goes five to 7 years in between proactive cleanings, unless you have understood roots.

Here is a simple property owner routine list that spends for itself lot of times over:

- Strain every sink and empty the strainer into the trash, not the disposal.
- Keep trees with aggressive roots a minimum of ten feet from the structure sewer, and water them far from the line so they do not chase after moisture.
- Fix any running toilet within 2 days, and test flappers yearly with a couple of drops of food coloring.
- Install a cleanout on the main if you do not have one, so future drain cleaning is exact, quick, and cheaper.
- Schedule an electronic camera inspection if you have 2 or more downturns in a year, even if they clear with plunging.

Those five practices have actually avoided more emergency situation calls than any bottled product on a shelf.

The quiet mathematics of timely septic pumping

A septic system separates and absorbs. That just works if you offer it time and room. The schedule for septic pumping is not a superstitious notion. It is a function of tank size, real water use, and solids loading.

Here is what I utilize as a beginning point. For a 1,000 gallon tank serving an average family of four, plan on pumping every 2.5 to 3.5 years. If you run a garbage disposal typically, shift that earlier by 6 to twelve months. A 1,500 gallon tank with the exact same family can stretch to four or five years. If it is a vacation home with seasonal use, 5 to seven years might be great. Those are guidelines. The better way is to measure.

Any competent pumper can take a core in the tank that shows residue thickness and sludge depth. When the combined residue and sludge layers near 30 to 35 percent of tank volume, you are due. If the outlet filter is caked or the effluent looks turbid, you have actually already waited too long. Ask your pumper to tape-record those measurements on the invoice. Keep them with your home papers. You will see your own pattern and adjust your schedule.

People in some cases stress over overpumping. You can not hurt a tank by pumping it when a year, besides spending more than required. In some jurisdictions with inspection programs, annual checks are required and pumping can fold into that visit. In cold environments, select shoulder seasons so access covers are not frozen and the ground is firm. If your tank covers are buried, have risers set up to bring them to grade. A riser set expenses money once and repays you in time, safety, and avoidance of yard damage during every future service.

Septic pumping expenses differ by region. In my area a standard pump out for a 1,000 to 1,250 gallon tank runs 300 to 700 dollars, depending upon lid depth, filter cleaning, and distance from the truck. Add a small cost for an effluent filter if you do not have one currently. That filter is one of the most inexpensive forms of insurance in this whole conversation. It keeps solids that slip past the baffle from heading to the field. Tidy the filter when you pump, and in between pumps if you ever see sluggish drains after a rise of visitors.

A practical structure to decide what to do next

When something fails, feelings increase. Raw sewage in the tub panics even stoic folks. A framework keeps rash moves in check and guides you from basic to complex.

- Identify the scope of the sign. If only the kitchen area sink is slow while a restroom on the exact same level drains well, the problem is local to that branch. If toilets on the lowest floor are bubbling while upstairs runs fine, believe the main to the tank. If components throughout the entire house sluggish throughout heavy use, think tank or field.
- Stabilize and collect information. Stop heavy water utilize for 12 to 24 hr. Lift the sewage-disposal tank cover if you can do so securely. A tank that is to the leading with the outlet immersed points to a field or outlet

blockage. A tank at typical operating level, with water leaving, recommends the limitation is upstream.

- Choose the least intrusive repair that your information supports. Regional branch concern, schedule targeted drain cleaning, preferably with a video camera. Mainline concerns, tidy from the cleanout towards the tank with a jetter or cable television, then electronic camera to validate condition. Tank overfull, require septic pumping and inspect the outlet filter and circulation box.
- Verify the outcome. After any cleaning or pumping, run regulated water at known volumes and see bottom lines. If you pumped a tank that was completed and the field still refuses to accept typical circulations within a day or two, intensify. That escalation may be a supplier or lateral line jet, a soil examination, or a repair at the circulation box.
- Decide in between repair and maintenance. If a cam reveals balanced out joints, root invasions every few feet, or a collapsed section, prepare a sectional septic repair or full line replacement. If the field reveals chronic breakout in multiple zones with a mature system, bring a certified designer to examine life left and alternatives for brand-new septic installation.

Most calls follow that path. A family I dealt with last summer had 2 backups in 3 months. They had actually never cleaned up the kitchen line. We jetted 80 feet of inch-thick grease, then descaled a crusty cast iron primary. The tank, a 1,000 gallon system for a family of 5 with a heavy cooking schedule, had actually not been pumped in 6 years. We pumped, installed a riser and an effluent filter, and set a 2 year tip. That entire service ran about 1,600 dollars. The excavation they were being pitched by a less patient specialist would have started at 9,000 simply to change the structure sewer, and it would not have actually solved the grease that was ensured to reform.

Edge cases that change the plan

No 2 residential or commercial properties equal, and there are usage patterns that need custom-made rules.

Short term leasings load tenancy into weekends. I have customers who see eight showers an hour from afternoon to night. That pushes style circulations. For them, I advocate larger tanks, alarms on pump chambers, and quarterly checks of filters. We also map and label cleanouts so a local handyman can direct a service tech without the owner flying in.

Home services like hair salons or little commercial cooking areas on domestic septic systems need grease and hair management at the source. A passive grease interceptor before the kitchen area branch can avoid endless sewer cleaning calls. An easy hair trap system under hair shampoo sinks costs less than a single emergency situation go to and keeps the primary clear.

Cold areas bring frost and access problems. Arrange proactive work before the deep freeze. Set up risers to grade, not 5 inches below it, so covers do not ice under sod. If your gain access to is across soft yard in spring, plan pumping for late summer when the ground can support the truck. A 100 foot hose pull is typical. A 200 foot pull includes labor and sometimes a helper.

Additions and remodels change whatever. More bed rooms without a system assessment can overload a field in 2 years. If you are adding fixtures, call for a style review before framing. A modest septic repair or a new circulation box upgrade during building and construction is far cheaper than rework later on. I have actually rerouted lines around prepared patios just by being at the table a few weeks earlier.

Water treatment devices matter. Do not send backwash from iron filters or softeners to the septic. Send it to a dry well or approved dispersal different from the tank. Sump pumps, roofing drains, and backyard drains must never connect to the building sewer. I still discover them. When we eliminate them, lots of persistent slowdowns vanish.

When excavation is the best decision

You can do whatever right and still fulfill the shovel. Some failures are structural and some systems are just at the end of their design life.

A collapsed clay lateral that has actually ovaled and pinched shut will not hold a jetter open for long. I have seen such areas look brought back for a week then close like a squeezed straw. Video camera video footage that shows missing pipe or voids means it is time to dig or trenchless line where codes permit. In those cases, a thoughtful septic repair plan takes a look at depth, nearby energies, surface area remediation, and future gain access to. It likewise includes correct cleanouts so the new run is maintainable.





A leach field that has actually ponded for months, with multiple zones revealing breakout and no resting capability, is not a prospect for restoration by magic aeration gadgets. Some jurisdictions enable pressurized lateral jetting or soil fracturing with air to restore permeability in particular soils. I have seen modest enhancements from those techniques when the field was young and treated early. On older fields with a thick, mature biomat and fines plugging the soil interface, those measures are short lived. A certified designer can take percolation tests, map setbacks, and propose a new field or an alternative treatment system. Expect licenses and inspections. Anticipate staging to secure the rest of your yard.

Choosing a contractor for excavation matters. Try to find ones who do both sewer cleaning and installation. They see the full lifecycle and tend to position cleanouts and risers where future you will thank them. Request for camera video footage before and after. Ask how they will secure watering, how they will backfill, and what settlement guarantee they provide. I have customers who saved a thousand dollars picking the most affordable bid and lost twice that in sod replacement the next spring.

Small upgrades that construct long term resilience

Three small modifications make life simpler for everyone who will ever touch your system.

Install risers on your septic tank covers and an effluent filter at the outlet if you do not have one. Bring lids to grade, set them slightly proud if your backyard tends to develop mulch. Label them on a simple sketch with ranges from fixed points like a corner of the house.

Add full size cleanouts, 2 method where possible, on the main line just outside the structure. If the run to the tank is long, include an intermediate cleanout every 75 to 100 feet. Cleanouts decrease the requirement to pull toilets or run devices on roofings. They also permit sectional sewer cleaning without flooding the tank with debris.

Manage roots thoughtfully. Copper sulfate crystals have brief range and combined outcomes. Mechanical root cutting during hydro jetting or with a bladed cable television works, but it is a maintenance task, not a remedy. In lawns with chronic root invasion, we have actually set up root barriers at specific trenches and guided tree plantings far from the sewer passage. A little landscape preparation beats annual root battles.

On the behavioral side, audit water usage. Swap old flappers. Replace a 1990s leading loader that uses 30 to 40 gallons a load with a modern system that uses 12 to 18. Stagger showers when guests visit. All of that keeps the tank in its sweet spot where germs absorb and solids remain put.

Two brief stories that show the structure in action

A retired couple called after their hall bath gurgled twice in a month. They had actually been pitched a complete line replacement by a professional who scoped a few feet of orange, scaly cast iron from the closet flange and stated doom. We started with the structure. Scope of symptom, simply the most affordable bathroom and the cooking area after big dish nights. We jetted the kitchen area branch to a shiny interior and descaled the cast iron main while viewing by camera, then checked the go to the septic system. It was PVC beyond the very first twenty feet, in excellent shape. The tank was past due, residue thick and the filter choked. We pumped and set a 3 year period. Overall invested, 1,280 dollars. That was three years earlier. They have had no repeats, and the line replacement quote they avoided was 12,400 dollars plus a brand-new driveway patch.

A small breakfast cafe on a rural residential or commercial property called twice in six weeks for emergency sewer cleaning. Their sewer line ran to a grease trap, then to a sewage-disposal tank and field. We discovered the trap was undersized and never pumped on schedule. The outlet tee was missing out on. Kitchen personnel dumped fryer oil into the preparation sink during change outs. We set out a basic strategy. Quarterly trap service, staff training, a lid riser for fast gain access to, and month-to-month hot water flushes with a jetter port set up at the trap outlet so we could scour the brief run downstream. They likewise adjusted their septic pumping to annual for the first 2 years while the system shed its backlog of grease. The coffee shop went from four backups a year to none in eighteen months. They prevented a field replacement that the landlord had started to rate at 28,000 dollars.

Where sewer cleaning and septic repair fit together

Sewer cleaning, drain cleaning, septic pumping, septic repair, and septic installation are not separate worlds. They are chapters in the very same story. A smart owner mixes them, using cleaning and pumping to gather real information, then making repairs where an electronic camera and measurements say they will pay off. You only dig when the pipe is broken, the field is spent, or the design never ever fit the use. Everything else is maintenance, and maintenance beats excavation every time.

Start basic, stay curious, and construct the small habits that keep waste moving quietly along. If you have not mapped your system, do it this month. If you can not remember your last septic pumping, call and arrange one,

then write the date where you will see it. If your kitchen area sink has been clearing slower each season, set a time to jet and scope that branch. Give yourself alternatives before the yard develops into a task site.

The backhoe is a great tool on the ideal day. Ensure that day only comes when the realities are on its side.

Mid-State Sewer Service is a sewer and septic company

Mid-State Sewer Service is located in Freeland Michigan

Mid-State Sewer Service provides sewer services

Mid-State Sewer Service provides septic services

Mid-State Sewer Service offers drain cleaning

Mid-State Sewer Service offers hydro jetting

Mid-State Sewer Service offers sewer camera inspections

Mid-State Sewer Service offers septic tank cleaning

Mid-State Sewer Service offers septic system installation

Mid-State Sewer Service offers portable toilet rentals

Mid-State Sewer Service serves residential customers

Mid-State Sewer Service serves commercial customers

Mid-State Sewer Service operates twenty four seven

Mid-State Sewer Service is family owned

Mid-State Sewer Service is licensed and insured

Mid-State Sewer Service serves Mid Michigan

Mid-State Sewer Service serves Saginaw Midland and Bay City

Mid-State Sewer Service was established in twenty nineteen

Mid-State Sewer Service uses modern equipment

Mid-State Sewer Service provides emergency sewer services

Mid-State Sewer Service has a phone number of (989) 482-7976

Mid-State Sewer Service has an address of 8754 Cottonwood Dr, Freeland, MI 48623

Mid-State Sewer Service has a website <https://midstatesewer.com/>

Mid-State Sewer Service has Google Maps listing <https://maps.app.goo.gl/urD9gsPrLA1zzyy9>

Mid-State Sewer Service has Facebook page <https://www.facebook.com/MidStateSewer>

Mid-State Sewer Service has an YouTube channel <https://www.youtube.com/@Midstatesewerservice>

Mid-State Sewer Service won Top Septic Pumping 2025

Mid-State Sewer Service earned Best Septic Tank Cleaning Award 2024

Mid-State Sewer Service was awarded Best Portable Toilet Rental 2026

People Also Ask about Mid-State Sewer Service

What services does Mid-State Sewer Service provide?

Mid-State Sewer Service provides sewer cleaning septic services drain cleaning hydro jetting and camera inspections for residential and commercial customers.

Where is Mid-State Sewer Service located?

Mid-State Sewer Service is located in Freeland Michigan and serves surrounding Mid Michigan communities.

Does Mid-State Sewer Service offer emergency services?

Yes Mid-State Sewer Service offers emergency sewer and septic services to handle urgent issues at any time.

Is Mid-State Sewer Service available twenty four seven?

Mid-State Sewer Service operates twenty four seven to provide reliable service whenever customers need help.

What areas does Mid-State Sewer Service serve?

Mid-State Sewer Service serves Mid Michigan including Saginaw Midland and Bay City and nearby areas.

Does Mid-State Sewer Service offer septic tank cleaning?

Yes Mid-State Sewer Service offers septic tank cleaning and maintenance to keep systems running properly.

Can Mid-State Sewer Service perform sewer camera inspections?

Mid-State Sewer Service provides sewer camera inspections to diagnose problems inside pipes accurately.

Does Mid-State Sewer Service provide hydro jetting?

Yes Mid-State Sewer Service uses hydro jetting to clear tough clogs and buildup in sewer lines.

Is Mid-State Sewer Service licensed and insured?

Mid-State Sewer Service is licensed and insured giving customers confidence in their services.

Does Mid-State Sewer Service work with both residential and commercial clients?

Mid-State Sewer Service works with both residential and commercial clients for a wide range of sewer and septic needs.

Where is Mid-State Sewer Service located?

The Mid-State Sewer Service is conveniently located at 8754 Cottonwood Dr, Freeland, MI 48623. You can easily find directions on [Google Maps](#) or call at [\(989\) 482-7976](#) Monday thru Sunday 24-hours a day

How can I contact Mid-State Sewer Service?

You can contact Mid-State Sewer Service by phone at: [\(989\) 482-7976](#), visit their website at <https://midstatesewer.com/> or connect on social media via [Facebook](#) or [YouTube](#)

After a family outing to [Mid Michigan Children's Museum](#) many homeowners plan Septic Pumping Septic Tank Cleaning Drain Cleaning and Portable Toilet Rental for home and event preparation.